









INSTALLATION G3E

PARTS


1  Spare part carton	2  Weatherstrip #205/2	3  Sponge Seal	4  S4 AL. Kwick Klamp	5  Kwick Klamp Cover
6  Electric klamp lock	7  Wiring kit	8  Black Cable Tie	9  White Cable Tie	10  Adaptor Switch
11  JP 8-1/2 EDP Screw	12  JP 2x1/4 Screw	13  Remote Control Set	14  2.5m. Double Side Tape	15  Carryboy Resin Plate
16  Bushing	17  Gas Strut Sticker	18  Ball Strut	19  Installation Manual	20  Installation Check List

A Clean the surface of the truck top edge .


B Place the sponge seal the truck top edge.



C Put the hardtop on top for the sponge seal and align left and right properly.



D Install kwick klamp at 6 position points. (DETAIL A and DETAIL B)




DETAIL A

DETAIL B


: In case of installed bed liner , the bed liner must be drilled with a Ø20 mm. holesaw at the same level of truck's inner low edge.

INSTALLATION G3E


E Adjust the position of rear door latches both LH and RH by 13mm. spanner.



F Align and adjust with 2 steps rotary lock system.




WIRING DIAGRAM



- Fuse
- 15A Demister
- 5A REMOTE
- 5A Roomlamp


G Run the wiring kit and tie up with cable tie provided.




INSTALLATION G3E

Demister Wiring Method


- 1 Mark for the position to cut and drill at the front console. Cut arectangle hole size 30 X 82 mm. drill the hole with M6∅ follow the mark




- 2 Assemble the demister switch with the provided terminals. Insert it from the back to the front console.



- 3 Tighten M6 screw to fix the demister switch properly.




- 4 Run the wiring from the battery through the front bushing hole.




INSTALLATION G3E

- F** Put the gas strut sticker on as per detail A.
Install the weatherstrip over the rain channel edge and put along RH to LH as per detail B.



- G** Stick the provided Carryboy resin logo to the same level positions.



:Recommendation : Adjust and tighten bolts and nuts on the Kwick Klamp every 5,000 kilometers.